

Track-It™ USB Coin Cell Battery Replacement Instructions

For all Track-It USB models




Removing the Battery

To replace the battery, loosen the two screws on the back of the logger and remove the bottom case half.



CAUTION: Be careful upon removing the screws as they have very small plastic washers.

Simply pop out the battery.






Replacing the Battery

Be sure the replacement battery is a CR2032 3 V Lithium battery.

There are two prongs in the battery space. Prong A (see image) is for positioning and securing the battery.

Slide the replacement battery under the prong A as show right.

Gently push the battery down to put in place. The second prong will lay flat under the battery.



DO NOT DISPOSE of the lithium-ion batteries as unsorted municipal waste. The batteries need to be **RECYCLED** in accordance with local regulations. The batteries should be sent to a recycling center or returned to the factory using appropriate shipping methods.